Streamline

Clear Anodized 3-Knob Horizontal Panel
(491294)



18865 Goll St. San Antonio, TX 78266
Phone: 800-862-6658
Sales: sales@vintageair.com
Tech Support: tech@vintageair.com
www.vintageair.com

www.vintageair.com

Table of Contents

Cover.....1
Table of Contents.....2
Packing List/Parts Disclaimer.....3
Control Panel Dimensions and Installation.....4
Control Panel Installation (Cont.).....5
Gen IV Wiring Diagram.....6
Gen 5 Wiring Diagram.....7
Operation of Controls.....8
Packing List.....9

Important Notice–Please Read

This control panel is designed to only work with a Gen IV evaporator unit equipped with a 246204-PUA ECU (all ECU's on Gen 5 evaporators will work with this control). Please confirm that your unit has the proper ECU prior to installing the control panel as shown below. A replacement ECU can be purchased from Vintage Air if needed.

www.vintageair.com

Packing List: Control Panel Kit (491294)

No.	Qty.	Part No.	Description
1.	1	491293	Control Panel, Streamline 3-Knob Horizontal
2.	1	232007-VUR	Control Harness, Universal

**** Before beginning installation, open all packages and check contents of shipment. Please report any shortages directly to Vintage Air within 15 days. After 15 days, Vintage Air will not be responsible for missing or damaged items.**

1



2



NOTE: Images may not depict actual parts and quantities. Refer to packing list for actual parts and quantities.

Control Panel Dimensions



Level This Line

Control Panel Installation

1. Select a suitable location for the control panel, considering heater control valve location, wiring harness length and operator convenience.
2. After selecting a location for the control panel, mask the area 1 ½” (tall) x 4 ½” (wide).
3. Using the dimensions provided above, mark or scribe the control panel opening location onto the dash. When you are certain that your dimensions and markings are correct, cut the dash to make the control panel opening. **NOTE: Measure twice. Cut once. This opening MUST be a precise fit. Cut the opening undersize, and then file to fit. The mounting screws only hold the panel against the dash. They do not locate the panel laterally. If the opening is oversized, the panel may shift during use.**
4. Install the control panel face through the opening in the dash. Place the control panel PC board assembly behind the dash, and secure it to the control panel face using the (4) 8-32 x 3/8” screws (See Figure 1 and 2a, Page 5). **NOTE: When tightening the control panel mounting screws, hand tighten until the screw contacts the back side of the dash. Then, using a screwdriver, tighten an additional 1/2 turn. Do not over tighten, as this may cause damage to the PC board or the dash.**
5. Plug the control panel wiring harness into the control panel and the ECU on the evaporator (See Figure 2, Page 5).
6. Wire according to the wiring diagram on Page 6 for Gen IV systems or Page 7 for Gen 5 systems.

Control Panel Installation (Cont.)



Figure 1



Rear View

NOTE: When using a Vintage Air supplied control panel, connect the TAN 20 AWG wire from the Gen IV evaporator wiring harness (232010) or the Gen 5 evaporator wiring harness (231505) to the factory dash lights to enable panel backlighting.





Figure 2



Side View

Figure 2a

Gen IV Wiring Diagram



* Dash lamp is used only with type 232007-VUR harness.

** Warning: Always mount circuit breaker as close to the battery as possible. (NOTE: Wire between battery and circuit breaker is unprotected and should be carefully routed to avoid a short circuit).

*** Wide open throttle switch contacts close only at full throttle, which disables A/C compressor.

Gen 5 Wiring Diagram



*** Dash lamp (TAN wire) is used only with type 232007-VUR harness.**

**** Wide open throttle switch contacts close only at full throttle, which disables A/C compressor.**

***** Install fuse assemblies at or as near to the battery as possible.**

Operation of Controls

On Gen IV and Gen 5 systems with three lever/knob controls, the temperature control toggles between heat and A/C operations. To activate A/C, move the temperature lever/knob all the way to cold and then back it off to the desired vent temperature. For heat operation, move the temperature lever/knob all the way to hot and then adjust to the desired vent temperature. The blower will momentarily change speed, each time you toggle in and out of heat and A/C operations, to indicate the change.

Blower Speed
This lever/knob controls blower speed, from OFF to HI.

Mode Control
This lever/knob controls the mode positions, from DASH to FLOOR to DEFROST, with a blend in between.

Temperature Control
This lever/knob controls the temperature, from HOT to COLD.



A/C Operation

Blower Speed
Adjust to desired speed.

Mode Control
Adjust to desired mode position (DASH position recommended).

Temperature Control
For A/C operation, adjust to coldest position to engage compressor (Adjust between HOT and COLD to reach desired temperature).

Heat Operation

Blower Speed
Adjust to desired speed.

Mode Control
Adjust to desired mode position (FLOOR position recommended).

Temperature Control
For maximum heating, adjust to hottest position (Adjust between HOT and COLD to reach desired temperature).

Defrost/De-fog Operation

Blower Speed
Adjust to desired speed.

Temperature Control
Adjust to desired temperature.

Mode Control
Adjust to DEFROST position for maximum defrost, or between FLOOR and DEFROST positions for a bi-level blend (Compressor is automatically engaged).

www.vintageair.com

Packing List:
Control Panel Kit (491294)

No.	Qty.	Part No.	Description	
1.	1	491293	Control Panel, Streamline 3-Knob Horizontal	_____
2.	1	232007-VUR	Control Harness, Universal	_____

Checked By: _____
Packed By: _____
Date: _____

1



2



NOTE: Images may not depict actual parts and quantities.
Refer to packing list for actual parts and quantities.